



iBwave
Design

RELEASE NOTES

Version 25.2.0

© iBwave Solutions 2004 – 2025

All Rights Reserved

The information contained herein is the property of iBwave Solutions and is strictly confidential. Except as expressly authorized in writing by iBwave Solutions, the holder shall keep all information confidential, shall disclose it only to its employees with a need to know, and shall protect it, in whole or in part, from disclosure and dissemination to third parties with the same degree of care protect its own confidential information, but with no less than reasonable care. Except as expressly authorized in writing by iBwave Solutions, the holder is granted no rights to use the information herein. Information is subject to change without notice. iBwave Solutions reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

TABLE OF CONTENTS

| | |
|--|----------|
| STREAMLINE INDOOR WIRELESS NETWORK PLANNING | 1 |
| WHAT'S NEW IN VERSION 25.2? | 1 |
| Fixed Issues | 1 |
| NEXT STEPS..... | 2 |
| CONTACTING CUSTOMER CARE | 2 |

STREAMLINE INDOOR WIRELESS NETWORK PLANNING

The iBwave Design application is the most comprehensive software available for automated network design planning. Users can streamline the process of data collection, component selection, cost evaluation, design, validation, documentation, reporting and more. Significantly reduce the time spent on manual field work and increase cost savings.

WHAT'S NEW IN VERSION 25.2?

The iBwave Design Version 25.2 includes maintenance and stability items aimed at increasing the efficiency and quality of your wireless designs.

Fixed Issues

The following issues have been resolved in iBwave Design release 25.2:

| ID | DESCRIPTION |
|------------|---|
| CORE-10000 | Fixed issue with SS-RSRP Threshold for 5G Output Maps |
| CORE-10034 | Crash when generating packaged report with cable length NaN |
| CORE-10055 | IBWC import - incorrect refpoint Y/X offset on map when importing RSSI |
| CORE-10361 | Invalid Geometry cables can cause an exception in Unity GIS View |
| CORE-10407 | DeSens value of Off-air Theoretical path is blank after loading saved project |
| CORE-10459 | Improve the control for overflowing floor plan tabs |
| CORE-10585 | Doors & Windows buttons remain enabled after opening creation |
| CORE-10641 | Crash after re-generating Automatic Access Point Placement |
| CORE-10666 | Lengths unit in Project Properties is not changed after export to ibwm |
| CORE-10694 | Crash after switching System display mode |
| CORE-10789 | Crash when deleting Wireless Service after entering backspace |
| CORE-10896 | Crash when cloning multiple objects on Picture plan |
| CORE-7741 | DBEditor crashes in opening |
| CORE-9565 | Parser can hang in the loading phase |

NEXT STEPS

NEXT STEPS

- [Register to Attend a Live iBwave Product Suite Demo](#)
- [Buy Version 25.2](#)
- [Upgrade to Version 25.2](#)
- [Download the Free iBwave Viewer](#)

CONTACTING CUSTOMER CARE

If you encounter any problems during the installation or configuration of iBwave Design, or if you have any questions, please send your inquiries to Customer Care:

- Email: support@ibwave.com
- Phone:
 - Americas: 1 855 442 9283 or 1 855 4 iBwave
 - Europe: +212 6 58 42 84 41
 - MEA: +212 6 58 42 84 41
 - APAC: +63 998 532 4966

You can also:

- Log into the iBwave Customer Portal, and create a request in the **My Cases** section:
<https://my.ibwave.com>
- Check if your questions are answered in the **Knowledge Base** section of the iBwave Customer Portal



iBwave Solutions Inc.

T +1 514-397-0606

8500 Bd Décarie, 3rd floor,
Mont-Royal, QC, H4P 2N2

info@ibwave.com

www.ibwave.com